

Distributed by:






# NORDIC JOIST™

Chantiers Chibougamau Ltd. harvests its own trees, which enables Nordic products to adhere to strict quality control procedures throughout the manufacturing process. Every phase of the operation, from forest to the finished product, reflects our commitment to quality.

Nordic Engineered Wood I-joists use only fingerjointed black spruce lumber in their flanges, ensuring consistent quality, superior strength, and longer span carrying capacity.



For further technical information, please refer to the *Nordic Joist Construction Guide* or contact your local distributor. Consult the *Installation Guide for Residential Floors* for proper procedures.

## **MAXIMUM FLOOR SPANS**


LIVE LOAD = 40 psf, DEAD LOAD = 15 psf

LOIST	10107		SIMPLE	SPANS		multiple spans on centre spacing					
JOIST DEPTH	JOIST SERIES		ON CENTR	E SPACING							
DEI III	JERRES	12"	16"	19.2	24"	12"	16"	19.2"	24"		
	NI-20	15'-1"	14'-2"	13'-9"	13'-5"	16'-3"	15'-4"	14'-10"	14'-7"		
	NI-40x	16'-1"	15'-2"	14'-8"	14'-9"	17'-5"	16'-5"	15'-10"	15'-5"		
9-1/2"	NI-60	16'-3"	15'-4"	14'-10"	14'-11"	17'-7"	16'-7"	16'-0"	16'-1"		
	NI-70	1 <i>7</i> '-1"	16'-1"	15'-6"	15'-7"	18'-7"	17'-4"	16'-9"	16'-10"		
	NI-80	17'-3"	16'-3"	15'-8"	15'-9"	18'-10"	17'-6"	16'-11"	17'-0"		
	NI-20	16'-11"	16'-0"	15'-5"	15'-6"	18'-4"	17'-3"	16'-8"	16'-7"		
	NI-40x	18'-1"	17'-0"	16'-5"	16'-6"	20'-0"	18'-6"	17'-9"	17'-7"		
	NI-60	18'-4"	17'-3"	16'-7"	16'-9"	20'-3"	18'-9"	18'-0"	18'-1"		
11-7/8"	NI-70	19'-6"	18'-0"	17'-4"	17'-5"	21'-6"	19'-11"	19'-0"	19'-1"		
	NI-80	19'-9"	18'-3"	17'-6"	17'-7"	21'-9"	20'-2"	19'-3"	19'-4"		
	NI-90	20'-2"	18'-7"	17'-10"	1 <i>7</i> '-11"	22'-3"	20'-7"	19'-8"	19'-9"		
	NI-90x	20'-4"	18'-9"	1 <i>7</i> '-11"	18'-0"	22'-5"	20'-9"	19'-10"	19'-11"		
	NI-40x	20'-1"	18'-7"	17'-10"	1 <i>7</i> '-11"	22'-2"	20'-6"	19'-8"	19'-4"		
	NI-60	20'-5"	18'-11"	18'-1"	18'-2"	22'-7"	20'-11"	20'-0"	20'-1"		
14"	NI-70	21'-7"	20'-0"	19'-1"	19'-2"	23'-10"	22'-1"	21'-1"	21'-2"		
14	NI-80	21'-11"	20'-3"	19'-4"	19'-5"	24'-3"	22'-5"	21'-5"	21'-6"		
	NI-90	22'-5"	20'-8"	19'-9"	19'-10"	24'-9"	22'-10"	21'-10"	21'-10"		
	NI-90x	22'-7"	20'-11"	19'-11"	20'-0"	25'-0"	23'-1"	22'-0"	22'-2"		
	NI-60	22'-3"	20'-8"	19'-9"	19'-10"	24'-7"	22'-9"	21'-9"	21'-10"		
	NI-70	23'-6"	21'-9"	20'-9"	20'-10"	26'-0"	24'-0"	22'-11"	23'-0"		
16"	NI-80	23'-11"	22'-1"	21'-1"	21'-2"	26'-5"	24'-5"	23'-3"	23'-4"		
	NI-90	24'-5"	22'-6"	21'-5"	21'-6"	26'-11"	24'-10"	23'-9"	23'-9"		
	NI-90x	24'-8"	22'-9"	21'-9"	21'-10"	27'-3"	25'-2"	24'-0"	24'-1"		

## NOTES:

- Maximum clear span applicable to residential floor construction with a design live load of 40 psf and dead load of 15 psf. The ultimate limit states are
  based on the factored loads of 1.50L + 1.25D. The serviceability limit states include the consideration for floor vibration, a live load deflection limit of
  L/480 and a total load deflection limit of L/240. For multiple-span applications, the end spans shall be 40% or more of the adjacent span.
- 2. Spans are based on a composite floor with glued-nailed oriented strand board (OSB) sheathing with a minimum thickness of 5/8 inch for a joist spacing of 19.2 inches or less, or 3/4 inch for joist spacing of 24 inches. Adhesive shall meet the requirements given in CGBS-71.26 Standard. No concrete topping or bridging element was assumed.
- 3. Minimum bearing length shall be 1-3/4 inches for the end bearings, and 3-1/2 inches for the intermediate bearings.
- 4. Bearing stiffeners are not required when I-joists are used with the spans and spacing given in these tables, except as required for hangers.
- 5. This span chart is based on uniform loads. For applications with other than uniformly distributed loads, an engineering analysis may be required based on the use of the design properties.

## **NORDIC JOIST™**





## **MAXIMUM ROOF SPANS**

SNOW LOAD = 40 psf, DEAD LOAD = 15 psf

TOLOT	LOIST	SLOPE	OF 1/4:12 TC	4:12	SLOPI	E OF >4:12 TC	8:12	SLOPE OF >8:12 TO 12:12 ON CENTRE SPACING			
JOIST DEPTH	JOIST SERIES	ON	CENTRE SPAC	ING	ON	CENTRE SPAC	ING				
DEFIII	JENIES	12"	16"	24"	12"	16"	24"	12"	16"	24"	
	NI-20	17'-4"	15'-8"	13'-7"	16'-7"	15'-0"	13'-0"	15'-5"	14'-0"	12'-1"	
	NI-40x	19'-10"	1 <i>7</i> '-11"	15'-4"	19'-0"	17'-2"	14'-11"	17'-8"	16'-0"	13'-11"	
9-1/2"	NI-60	20'-2"	18'-3"	15'-10"	19'-5"	17'-6"	15'-2"	18'-0"	16'-4"	14'-2"	
	NI-70	22'-2"	20'-0"	17'-4"	21'-3"	19'-2"	16'-8"	19'-9"	1 <i>7</i> '-11"	15'-6"	
	NI-80	22'-7"	20'-5"	17'-8"	21'-8"	19'-7"	17'-0"	20'-2"	18'-3"	15'-10"	
	NI-20	20'-11"	18'-11"	16'-5"	20'-0"	18'-2"	15'-9"	18'-8"	16'-11"	14'-8"	
	NI-40x	23'-9"	21'-5"	17'-6"	22'-9"	20'-7"	17'-2"	21'-2"	19'-2"	16'-8"	
	NI-60	24'-3"	21'-11"	19'-0"	23'-3"	21'-1"	18'-3"	21'-8"	19'-7"	17'-0"	
11-7/8"	NI-70	26'-5"	23'-11"	20'-9"	25'-5"	23'-0"	19'-11"	23'-8"	21'-5"	18'-7"	
	NI-80	27'-0"	24'-5"	21'-1"	25'-11"	23'-5"	20'-4"	24'-1"	21'-10"	18'-11"	
	NI-90	27'-10"	25'-2"	21'-9"	26'-9"	24'-2"	20'-11"	24'-10"	22'-6"	19'-6"	
	NI-90x	28'-1"	25'-4"	21'-11"	26'-11"	24'-4"	21'-1"	25'-1"	22'-8"	19'-8"	
	NI-40x	26'-11"	23'-7"	19'-2"	25'-10"	23'-2"	18'-10"	24'-1"	21'-9"	18'-5"	
	NI-60	27'-8"	25'-0"	21'-8"	26'-6"	24'-0"	20'-10"	24'-8"	22'-4"	19'-5"	
14"	NI-70	30'-0"	27'-2"	23'-6"	28'-10"	26'-1"	22'-7"	26'-10"	24'-3"	21'-1"	
14	NI-80	30'-8"	27'-9"	24'-1"	29'-6"	26'-8"	23'-2"	27'-5"	24'-10"	21'-7"	
	NI-90	31'-7"	28'-7"	24'-9"	30'-4"	27'-6"	23'-10"	28'-3"	25'-7"	22'-2"	
	NI-90x	32'-0"	28'-11"	25'-1"	30'-9"	27'-10"	24'-1"	28'-7"	25'-11"	22'-6"	
	NI-60	30'-9"	27'-10"	23'-9"	29'-6"	26'-8"	23'-2"	27'-5"	24'-10"	21'-7"	
	NI-70	33'-3"	30'-1"	25'-9"	31'-11"	28'-11"	25'-1"	29'-9"	26'-11"	23'-4"	
16"	NI-80	34'-1"	30'-10"	26'-9"	32'-8"	29'-7"	25'-8"	30'-5"	27'-7"	23'-11"	
	NI-90	35'-0"	31'-8"	27'-5"	33'-7"	30'-5"	26'-5"	31'-4"	28'-4"	24'-7"	
	NI-90x	35'-7"	32'-2"	27'-11"	34'-2"	30'-11"	26'-10"	31'-10"	28'-9"	25'-0"	

## **MAXIMUM ROOF SPANS**

SNOW LOAD = 50 psf, DEAD LOAD = 15 psf

JOIST DEPTH	LOIST	SLOPE	OF 1/4:12 TC	4:12	SLOP	E OF >4:12 TC	8:12	SLOPE OF >8:12 TO 12:12 ON CENTRE SPACING			
	JOIST SERIES	ON	CENTRE SPAC	ING	ON	CENTRE SPAC	ING				
	JENIES	12"	16"	24"	12"	16"	24"	12"	16"	24"	
	NI-20	16'-0"	14'-6"	12'-6"	15'-4"	13'-11"	12'-0"	14'-7"	13'-2"	11'-5"	
	NI-40x	18'-4"	16'-7"	14'-0"	17'-7"	15'-11"	13'-9"	16'-8"	15'-1"	13'-1"	
9-1/2"	NI-60	18'-8"	16'-11"	14'-7"	1 <i>7</i> '-11"	16'-3"	14'-0"	17'-0"	15'-5"	13'-4"	
	NI-70	20'-5"	18'-6"	16'-0"	19'-8"	17'-9"	15'-4"	18'-8"	16'-11"	14'-8"	
	NI-80	20'-11"	18'-10"	16'-4"	20'-1"	18'-2"	15'-8"	19'-1"	17'-3"	14'-11"	
11-7/8"	NI-20	19'-4"	17'-6"	15'-1"	18'-7"	16'-9"	14'-7"	17'-7"	15'-11"	13'-10"	
	NI-40x	21'-11"	19'-8"	16'-0"	21'-1"	19'-1"	15'-9"	20'-0"	18'-1"	15'-5"	
	NI-60	22'-5"	20'-3"	17'-7"	21'-6"	19'-6"	16'-10"	20'-5"	18'-6"	16'-1"	
	NI-70	24'-6"	22'-1"	19'-1"	23'-6"	21'-3"	18'-5"	22'-4"	20'-2"	17'-6"	
	NI-80	24'-11"	22'-7"	19'-6"	24'-0"	21'-8"	18'-9"	22'-9"	20'-7"	17'-10"	
	NI-90	25'-9"	23'-3"	20'-1"	24'-9"	22'-4"	19'-4"	23'-6"	21'-3"	18'-5"	
	NI-90x	25'-11"	23'-5"	20'-3"	24'-11"	22'-6"	19'-6"	23'-8"	21'-5"	18'-7"	
	NI-40x	24'-11"	21'-7"	17'-7"	23'-11"	21'-3"	17'-4"	22'-9"	20'-7"	17'-0"	
	NI-60	25'-7"	23'-2"	20'-0"	24'-7"	22'-3"	19'-3"	23'-4"	21'-1"	18'-4"	
14"	NI-70	27'-9"	25'-1"	21'-8"	26'-8"	24'-1"	20'-11"	25'-4"	22'-11"	19'-11"	
14	NI-80	28'-5"	25'-8"	22'-3"	27'-3"	24'-8"	21'-4"	25'-11"	23'-5"	20'-4"	
	NI-90	29'-3"	26'-5"	22'-10"	28'-1"	25'-5"	22'-0"	26'-8"	24'-2"	20'-11"	
	NI-90x	29'-7"	26'-9"	23'-2"	28'-5"	25'-9"	22'-3"	27'-0"	24'-5"	21'-2"	
	NI-60	28'-5"	25'-9"	21'-8"	27'-4"	24'-8"	21'-5"	25'-11"	23'-6"	20'-4"	
	NI-70	30'-9"	27'-10"	21'-8"	29'-7"	26'-9"	23'-2"	28'-1"	25'-5"	22'-1"	
16"	NI-80	31'-6"	28'-6"	23'-1"	30'-3"	27'-5"	23'-9"	28'-9"	26'-0"	22'-7"	
	NI-90	32'-5"	29'-3"	25'-4"	31'-1"	28'-2"	24'-5"	29'-7"	26'-9"	23'-3"	
	NI-90x	32'-11"	29'-9"	25'-9"	31'-7"	28'-7"	24'-9"	30'-0"	27'-2"	23'-7"	

#### NOTES

- 1. Allowable clear span applicable to simple-span roof construction with a design roof snow load as shown and dead load of 15 psf. The allowable span is based on the horizontal distance between inside face of supports. The snow load deflection is limited to L/240 and the total load deflection to L/180. Spans are based on a duration of load (DOL) factor of 1.15.
- 2. Spans include a cantilever of up to 2 feet on one end of the I-joist.
- 3. Minimum bearing length shall be 1-3/4 inches for the end bearings, and 3-1/2 inches on end bearing adjacent to cantilever.
- 4. Bearing stiffeners are not required when I-joists are used with the spans and spacing given in these tables, except as required for hangers.
- 5. These span charts are based on uniform loads. For applications with other than uniformly distributed loads, an engineering analysis may be required based on the use of the design properties.

# TABLE 1 HOLE SIZES AND LOCATIONS — Simple or Multiple Span

IOICT	TOIST	MINIMUM DISTANCE FROM INSIDE FACE OF ANY SUPPORT TO CENTRE OF HOLE (ft-in.)														
JOIST DEPTH	JOIST		ROUND HOLE DIAMETER (in.)													
DEFIR	SERIES	2	3	4	5	6	6-1/4	7	8	8-5/8	9	10	10-3/4	11	12	12-3/4
	NI-20	0'-7"	1'-6"	2'-10"	4'-3"	5'-8"	6'-0"									
	NI-40x	0'-7"	1'-6"	3'-0"	4'-4"	6'-0"	6'-4"									
9-1/2"	NI-60	1'-3"	2'-6"	4'-0"	5'-4"	7'-0"	7'-5"									
	NI-70	2'-0"	3'-4"	4'-9"	6'-3"	8'-0"	8'-4"									
	NI-80	2'-3"	3'-6"	5'-0"	6'-6"	8'-2"	8'-8"									
	NI-20	0'-7"	0'-8"	1'-0"	2'-4"	3'-8"	4'-0"	5'-0"	6'-6"	7'-9"						
	NI-40x	0'-7"	0'-8"	1'-3"	2'-8"	4'-0"	4'-4"	5'-5"	7'-0"	8'-4"						
	NI-60	0'-7"	1'-8"	3'-0"	4'-3"	5'-9"	6'-0"	7'-3"	8'-10"	10'-0"						
11-7/8"	NI-70	1'-3"	2'-6"	4'-0"	5'-4"	6'-9"	7'-2"	8'-4"	10'-0"	11'-2"						
	NI-80	1'-6"	2'-10"	4'-2"	5'-6"	7'-0"	7'-5"	8'-6"	10'-3"	11'-4"						
	NI-90	0'-7"	0'-8"	1'-5"	3'-2"	4'-10"	5'-4"	6'-9"	8'-9"	10'-2"						
	NI-90x	0'-7"	0'-8"	0'-9"	2'-5"	4'-4"	4'-9"	6'-3"	51.01			01.01	10.0"			
	NI-40x	0'-7"	0'-8"	0'-8"	1'-0"	2'-4"	2'-9"	3'-9"	5'-2"	6'-0"	6'-6"	8'-3"	10'-2"			
	NI-60	0'-7"	0'-8"	1'-8"	3'-0"	4'-3"	4'-8"	5'-8"	7'-2"	8'-0"	8'-8"	10'-4"	11'-9"			
14"	NI-70	0'-8"	1'-10"	3'-0"	4'-5"	5'-10"	6'-2"	7'-3"	8'-9"	9'-9"	10'-4"	12'-0"	13'-5"			
	NI-80	0'-10"	2'-0"	3'-4"	4'-9"	6'-2"	6'-5"	7'-6"	9'-0"	10'-0"	10'-8"	12'-4"	13'-9"			
	NI-90	0'-7"	0'-8"	0'-10"	2'-5"	4'-0"	4'-5"	5'-9"	7'-5"	8'-8"	9'-4"	11'-4"	12'-11"			
	NI-90x	0'-7"	0'-8"	0'-8"	2'-0"	3'-9"	4'-2"	5'-5"	7'-3"	8'-5"	9'-2"					
	NI-60	0'-7"	0'-8"	0'-8"	1'-6"	2'-10"	3'-2"	4'-2"	5'-6"	6'-4"	7'-0"	8'-5"	9'-8"	10'-2"	12'-2"	13'-9"
1.71	NI-70	0'-7"	1'-0"	2'-3"	3'-6"	4'-10"	5'-3"	6'-3"	7'-8"	8'-6"	9'-2"	10'-8"	12'-0"	12'-4"	14'-0"	15'-6"
16"	NI-80	0'-7"	1'-3"	2-6"	3'-10"	5'-3"	5'-6"	6'-6"	8'-0"	9'-0"	9'-5"	11'-0"	12'-3"	12'-9"	14'-5"	16'-0"
	NI-90	0'-7"	0'-8"	0'-8"	1'-9"	3'-3"	3'-8"	4'-9"	6'-5"	7'-5"	8'-0"	9'-10"	11'-3"	11'-9"	13'-9"	15'-4"
	NI-90x	0'-7"	0'-8"	0'-9"	2'-0"	3'-6"	4'-0"	5'-0"	6'-9"	7'-9"	8'-4"	10'-2"	11'-6"	12'-0"		

TABLE 2


## **DUCT CHASE OPENING SIZES AND LOCATIONS — Simple Span Only**

JOIST DEPTH	TOICT	MINIMUM DISTANCE FROM INSIDE FACE OF ANY SUPPORT TO CENTRE OF OPENING (ft-in.)										
	JOIST	DUCT CHASE LENGTH (in.)										
DEFIN	SERIES	8	10	12	14	16	18	20	22	24		
9-1/2"	NI-20 NI-40x NI-60 NI-70 NI-80	4'-1" 5'-3" 5'-4" 5'-1" 5'-3"	4'-5" 5'-8" 5'-9" 5'-5" 5'-8"	4'-10" 6'-0" 6'-2" 5'-10" 6'-0"	5'-4" 6'-5" 6'-7" 6'-3" 6'-5"	5'-8" 6'-10" 7'-1" 6'-7" 6'-10"	6'-1" 7'-3" 7'-5" 7'-1" 7'-3"	6'-6" 7'-8" 8'-0" 7'-6" 7'-8"	7'-1" 8'-2" 8'-3" 8'-1" 8'-2"	7'-5" 8'-6" 8'-9" 8'-4" 8'-6"		
11-7/8"	NI-20 NI-40x NI-60 NI-70 NI-80 NI-90 NI-90x	5'-9" 6'-8" 7'-3" 7'-1" 7'-2" 7'-6" 7'-7"	6'-2" 7'-2" 7'-8" 7'-4" 7'-7" 7'-11" 8-1"	6'-6" 7'-6" 8'-0" 7'-9" 8'-0" 8'-4" 8'-5"	7'-1" 8'-1" 8'-6" 8'-3" 8'-5" 8'-9" 8'-10"	7'-5" 8'-6" 9'-0" 8'-7" 8'-10" 9'-2" 9'-4"	7'-9" 9'-1" 9'-3" 9'-1" 9'-3" 9'-7" 9'-8"	8'-3" 9'-6" 9'-9" 9'-6" 9'-8" 10'-1" 10'-2"	8'-9" 10'-1" 10'-3" 10'-1" 10'-2" 10'-7" 10'-8"	9'-4" 10'-9" 11'-0" 10'-4" 10'-8" 10'-11"		
14"	NI-40x NI-60 NI-70 NI-80 NI-90 NI-90x	8'-1" 8'-9" 8'-7" 9'-0" 9'-2" 9'-4"	8'-7" 9'-3" 9'-1" 9'-3" 9'-8" 9'-9"	9'-0" 9'-8" 9'-5" 9'-9" 10'-0"	9'-6" 10'-1" 9'-10" 10'-1" 10'-6" 10'-7"	10'-1" 10'-6" 10'-4" 10'-7" 10'-11"	10'-7" 11'-1" 10'-8" 11'-1" 11'-5" 11'-7"	11'-2" 11'-6" 11'-2" 11'-6" 11'-9" 12'-1"	12'-0" 13'-3" 11'-7" 12'-1" 12'-4" 12'-7"	12'-8" 13'-0" 12'-3" 12'-6" 12'-11"		
16"	NI-60 NI-70 NI-80 NI-90 NI-90x	10'-3" 10'-1" 10'-4" 10'-9" 11'-1"	10'-8" 10'-5" 10'-9" 11'-2" 11'-5"	11'-2" 11'-0" 11'-3" 11'-8" 11'-10"	11'-6" 11'-4" 11'-9" 12'-0" 12'-4"	12'-1" 11'-10" 12'-1" 12'-6" 12'-10"	12'-6" 12'-3" 12'-7" 13'-0" 13'-2"	13'-2" 12'-8" 13'-1" 13'-6" 13'-9"	14'-1" 13'-3" 13'-8" 14'-2" 14'-4"	14'-10" 14'-0" 14'-4" 14'-10" 15'-2"		

#### NOTES:

- 1. Above table may be used for I-joist spacing of 24 inches on centre or less.
- 2. Hole and duct chase opening location distance is measured from inside face of supports to centre of hole or opening.
- 3. For continuous joists with more than one span, use the longest span to determine hole location in either span.
- 4. Distances are based on uniformly loaded floor joists that meet the span requirements for a design live load of 40 psf and dead load of 15 psf, and a live load deflection limit of L/480.
- 5. The maximum size hole or the maximum depth of a duct chase opening that can be cut into an I-joist web shall equal the clear distance between the flanges of the I-joist minus 1/4 inch (maintain a minimum of 1/8 inch between the top or bottom of the hole or opening and the adjacent I-joist flange).
- 6. The duct chase opening table is based on simple-span joists only. For other applications, contact your local distributor.
- 7. The above tables are based on the I-joists being used at their maximum spans. The minimum distance as given above may be reduced for shorter spans; contact your local distributor.

## FIELD-CUT HOLE LOCATOR



Knockouts are prescored holes provided for the contractor's convenience to install electrical or small plumbing lines. They are 1-1/2 inches in diameter, and are spaced 15 inches on centre along the length of the I-joist. Where possible, it is preferable to use knockouts instead of field-cut holes.



**Never** drill, cut or notch the flange, or over-cut the web.

Holes in webs should be cut with a sharp saw.

For rectangular holes, avoid over-cutting the corners, as this can cause unnecessary stress concentrations. Slightly rounding the corners is recommended. Starting the rectangular hole by drilling a 1-inch diameter hole in each of the four corners and then making the cuts between the holes is another good method to minimize damage to the 1-joist.



Sustainable Wood Solutions

## **HEAD OFFICE AND TECHNICAL SERVICES**

info@nordicewp.com • www.nordicewp.com T. 514.871.8526 • F. 514.871.9789

